


Spare Parts

ST-2620F Foamer System

Item-No. 202620915



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	01 0007 333	Housing M 18 x 1,5 female	15	02 0009 550	Label Suttner Foam
2	07 0001 157	Pipe inlet	16	07 0001 860	nozzle pipe
3	04 0001 895	Turning part G1/2 FT	17	04 0005 295	inlet nut
4	04 0001 855	Adaptor	18	12 0502 002	nozzle
5	20 0340 100	Repair-Kit Swivel	19	02 0001 147	Nozzleprotection
6	20 2300 380	Piston rod complete	20	02 0003 515	Pipe
7	04 0007 060	Pin	21	02 0002 482	washer
8	04 0007 059	Support plate	22	20 2710 480	Valve seat complete
9	04 0007 081	Axle for trigger	23	02 0000 450	Valve cone
10	20 2600 400	Pressure roller complete	24	06 0002 055	Spring
11	20 2600 425	Trigger complete	25	01 0007 345	Screw plug
12	02 0008 615	Plastic housing with handle	26	05 0001 521	O-ring 10x1,5
13	02 0008 620	Plastic housing			
14	04 0000 051	Screw 3.5x16			